


ACS580-01...+C135, ACH580-01...+C135 and ACQ580-01...+C135 frames R4 and R5 flange mounting kit quick installation guide ABB parts Available as option +C135 and separately with ordering codes: 3AXD50000031460 (R4) and 3AXD50000031461 (R5). R4 IP21 (UL Type 1) IP21 [UL Type 1] and IP55 [UL Type 12] for frame R4. IP21 [UL Type 1] for R5. For IP55 (UL Type 12) the plug is installed at the factory. (i) 4 × M5×20 screw 3 N·m 4 × M6 nut 8 × M6 nut 6 N·m 6 N⋅m (d)4 × M5×20 screw 16 × M6×25 screw 23 × M6 nut Note: Attach this end to the bottom U-bracket to make ② 2 x M4 nut e sure that the sealing is tight. 2 × M4 nut **Note:** First attach the inner sides of the brackets (1) that touch the drive, then the outer sides (2). 1 N·m Frames R4 and R5 Frame R5 only 8 × M6 nut 6 N·m Note: Wear protective gloves when operating.





(i)

Rivet/Kalei nuts are not included in the delivery.




Note: Mounting templates are different (size, number and position of holes) for different frame size.







UL Type 12 only UL Type 12 is fulfilled on the drive backside when the flange and hood are installed. Hood is not required for IP55. 3 x M6 nuts Hood (view from top) 6 N·m Back Front Hood (view from bottom)

1 × M6×25 screw 6 N·m







For dimensions, see the mounting template delivered with the flange mounting kit or *ACS580-01...+C135*, ACH580-01...+C135 and ACQ580-01...+C135 drives with flange mounting kit supplement (3AXD50000349821 [English]).

Go to www.abb.com/drives.



ACS580-01 manuals



ACH580-01 manuals



ACQ580-01 manuals