



W34 enclosed S611 (stocked)

Table 1. S611 Horsepower Ratings Based on 300% Standard Duty

| Max. Current | 60 Hz—300% Duty | | | | Enclosure | | | Disconnect | | | Transformer | Cover Control | |
|--------------|-----------------|------|------|------|-----------|---------|--------|------------|---------|---------|-------------|---------------|------------|
| | 208V | 240V | 480V | 600V | NEMA 12 | NEMA 3R | NEMA 4 | Non-Combo | Fusible | Breaker | CPT | HOA | Start/Stop |
| 52A | 15 | 15 | 40 | 50 | | ■ | | | | ■ | | ■ | ■ |
| 65A | 20 | 20 | 50 | 60 | | | | | | | | | |
| 77A | 25 | 25 | 60 | 75 | | ■ | | | | ■ | | ■ | ■ |
| 99A | 30 | 30 | 75 | 100 | ■ | ■ | | | | ■ | | ■ | ■ |
| 125A | 40 | 40 | 100 | 125 | | ■ | | | | ■ | | ■ | ■ |
| 156A | 50 | 60 | 125 | 150 | | | | | | | | | |
| 180A | 60 | 60 | 150 | 150 | ■ | ■ | | | | ■ | | ■ | ■ |
| 242A | 75 | 75 | 200 | 250 | | ■ | | | | ■ | | ■ | ■ |
| 302A | 100 | 100 | 250 | 300 | | | | | | | | | |
| 361A | 125 | 150 | 300 | 350 | | | | | | | | | |
| 414A | 150 | 150 | 350 | 450 | | | | | | | | | |

Note: Door-mounted keypad and pump control S611 are provided as standard.

Effective November 2012

Table 2. W34 Stocked Enclosed S611

| Description | Catalog Number |
|---|-------------------|
| COMBO BREAKER (70A) 52A NEMA 3R S611 480 Vac, CPT, START/STOP PB, HOA | ECS98R2CAW-C1P7S3 |
| COMBO BREAKER (100A) 77A NEMA 3R S611 480 Vac, CPT, START/STOP PB, HOA | ECS98T2CAG-C1P7S3 |
| COMBO BREAKER (150A) 99A NEMA 3R S611 480 Vac, CPT, START/STOP PB, HOA | ECS98V2CAH-C1P7S3 |
| COMBO BREAKER (150A) 125A NEMA 3R S611 480 Vac, CPT, START/STOP PB, HOA | ECS98W2CAH-C1P7S3 |
| COMBO BREAKER (250A) 180A NEMA 3R S611 480 Vac, CPT, START/STOP PB, HOA | ECS98Y2CAJ-C1P7S3 |
| COMBO BREAKER (400A) 242A NEMA 3R S611 480 Vac, CPT, START/STOP PB, HOA | ECS98Z2CAK-C1P7S3 |
| COMBO BREAKER (150A) 99A NEMA 12 S611 575 Vac, CPT, START/STOP PB, HOA | ECS98V8DAH-C1P7S3 |
| COMBO BREAKER (250A) 180A NEMA 12 S611 575 Vac, CPT, START/STOP PB, HOA | ECS98Y8DAJ-C1P7S3 |

Vista registered enclosed S611 (2 weeks lead-time)**Table 3. S611 Horsepower Ratings Based on 300% Standard Duty**

| Max. Current | 60 Hz—300% Duty | | | | Enclosure | | | Disconnect | | | Transformer | Cover Control | |
|--------------|-----------------|------|------|------|-----------|---------|--------|------------|---------|---------|-------------|---------------|------------|
| | 208V | 240V | 480V | 600V | NEMA® 12 | NEMA 3R | NEMA 4 | Non-Combo | Fusible | Breaker | CPT | HOA | Start/Stop |
| 52A | 15 | 15 | 40 | 50 | | ■ | | ■ | ■ | ■ | ■ | ■ | ■ |
| 65A | 20 | 20 | 50 | 60 | | ■ | | ■ | ■ | ■ | ■ | ■ | ■ |
| 77A | 25 | 25 | 60 | 75 | | ■ | | ■ | ■ | ■ | ■ | ■ | ■ |
| 99A | 30 | 30 | 75 | 100 | ■ | ■ | | ■ | ■ | ■ | ■ | ■ | ■ |
| 125A | 40 | 40 | 100 | 125 | | ■ | | ■ | ■ | ■ | ■ | ■ | ■ |
| 156A | 50 | 60 | 125 | 150 | | ■ | | ■ | ■ | ■ | ■ | ■ | ■ |
| 180A | 60 | 60 | 150 | 150 | ■ | ■ | | ■ | ■ | ■ | ■ | ■ | ■ |
| 242A | 75 | 75 | 200 | 250 | | ■ | | ■ | ■ | ■ | ■ | ■ | ■ |
| 302A | 100 | 100 | 250 | 300 | | | ■ | ■ | ■ | ■ | ■ | ■ | ■ |
| 361A | 125 | 150 | 300 | 350 | | | ■ | ■ | ■ | ■ | ■ | ■ | ■ |
| 414A | 150 | 150 | 350 | 450 | | | ■ | ■ | ■ | ■ | ■ | ■ | ■ |

Note: Door-mounted keypad and pump control S611 are provided as standard.

Table 4. Vista Registered Enclosed S611

| Description | Catalog Number |
|--|----------------|
| NON-COMBO 52A NEMA 3R S611 480 Vac | ECS96R2CAA |
| NON-COMBO 65A NEMA 3R S611 480 Vac | ECS96S2CAA |
| NON-COMBO 77A NEMA 3R S611 480 Vac | ECS96T2CAA |
| NON-COMBO 99A NEMA 3R S611 480 Vac | ECS96V2CAA |
| NON-COMBO 125A NEMA 3R S611 480 Vac | ECS96W2CAA |
| NON-COMBO 156A NEMA 3R S611 480 Vac | ECS96X2CAA |
| NON-COMBO 180A NEMA 3R S611 480 Vac | ECS96Y2CAA |
| NON-COMBO 242A NEMA 3R S611 480 Vac | ECS96Z2CAA |
| NON-COMBO 302A NEMA 4 PAINTED S611 480 Vac | ECS9613CAA |
| NON-COMBO 361A NEMA 4 PAINTED S611 480 Vac | ECS9623CAA |
| NON-COMBO 414A NEMA 4 PAINTED S611 480 Vac | ECS9633CAA |
| NON-COMBO 52A NEMA 3R S611 208 Vac | ECS96R2EAA |
| NON-COMBO 65A NEMA 3R S611 208 Vac | ECS96S2EAA |
| NON-COMBO 77A NEMA 3R S611 208 Vac | ECS96T2EAA |
| NON-COMBO 99A NEMA 3R S611 208 Vac | ECS96V2EAA |
| NON-COMBO 125A NEMA 3R S611 208 Vac | ECS96W2EAA |
| NON-COMBO 156A NEMA 3R S611 208 Vac | ECS96X2EAA |
| NON-COMBO 180A NEMA 3R S611 208 Vac | ECS96Y2EAA |
| NON-COMBO 242A NEMA 3R S611 208 Vac | ECS96Z2EAA |
| NON-COMBO 302A NEMA 4 PAINTED S611 208 Vac | ECS9613EAA |
| NON-COMBO 361A NEMA 4 PAINTED S611 208 Vac | ECS9623EAA |
| NON-COMBO 414A NEMA 4 PAINTED S611 208 Vac | ECS9633EAA |
| NON-COMBO 52A NEMA 3R S611 240 Vac | ECS96R2BAA |
| NON-COMBO 65A NEMA 3R S611 240 Vac | ECS96S2BAA |

Table 4. Vista Registered Enclosed S611, Continued

| Description | Catalog Number |
|---|-----------------------|
| NON-COMBO 77A NEMA 3R S611 240 Vac | ECS96T2BAA |
| NON-COMBO 99A NEMA 3R S611 240 Vac | ECS96V2BAA |
| NON-COMBO 125A NEMA 3R S611 240 Vac | ECS96W2BAA |
| NON-COMBO 156A NEMA 3R S611 240 Vac | ECS96X2BAA |
| NON-COMBO 180A NEMA 3R S611 240 Vac | ECS96Y2BAA |
| NON-COMBO 242A NEMA 3R S611 240 Vac | ECS96Z2BAA |
| NON-COMBO 302A NEMA 4 PAINTED S611 240 Vac | ECS9613BAA |
| NON-COMBO 361A NEMA 4 PAINTED S611 240 Vac | ECS9623BAA |
| NON-COMBO 414A NEMA 4 PAINTED S611 240 Vac | ECS9633BAA |
| NON-COMBO 52A NEMA 3R S611 575 Vac | ECS96R2DAA |
| NON-COMBO 65A NEMA 3R S611 575 Vac | ECS96S2DAA |
| NON-COMBO 77A NEMA 3R S611 575 Vac | ECS96T2DAA |
| NON-COMBO 99A NEMA 3R S611 575 Vac | ECS96V2DAA |
| NON-COMBO 125A NEMA 3R S611 575 Vac | ECS96W2DAA |
| NON-COMBO 156A NEMA 3R S611 575 Vac | ECS96X2DAA |
| NON-COMBO 180A NEMA 3R S611 575 Vac | ECS96Y2DAA |
| NON-COMBO 242A NEMA 3R S611 575 Vac | ECS96Z2DAA |
| NON-COMBO 302A NEMA 4 PAINTED S611 575 Vac | ECS9613DAA |
| NON-COMBO 361A NEMA 4 PAINTED S611 575 Vac | ECS9623DAA |
| NON-COMBO 414A NEMA 4 PAINTED S611 575 Vac | ECS9633DAA |
| NON-COMBO 52A NEMA 3R S611 480 Vac, CPT, START/STOP PB, HOA | ECS96R2CAA-C1P7S3 |
| NON-COMBO 65A NEMA 3R S611 480 Vac, CPT, START/STOP PB, HOA | ECS96S2CAA-C1P7S3 |
| NON-COMBO 77A NEMA 3R S611 480 Vac, CPT, START/STOP PB, HOA | ECS96T2CAA-C1P7S3 |
| NON-COMBO 99A NEMA 3R S611 480 Vac, CPT, START/STOP PB, HOA | ECS96V2CAA-C1P7S3 |
| NON-COMBO 125A NEMA 3R S611 480 Vac, CPT, START/STOP PB, HOA | ECS96W2CAA-C1P7S3 |
| NON-COMBO 156A NEMA 3R S611 480 Vac, CPT, START/STOP PB, HOA | ECS96X2CAA-C1P7S3 |
| NON-COMBO 180A NEMA 3R S611 480 Vac, CPT, START/STOP PB, HOA | ECS96Y2CAA-C1P7S3 |
| NON-COMBO 242A NEMA 3R S611 480 Vac, CPT, START/STOP PB, HOA | ECS96Z2CAA-C1P7S3 |
| NON-COMBO 302A NEMA 4 PAINTED S611 480 Vac, CPT, START/STOP PB, HOA | ECS9613CAA-C1P7S3 |
| NON-COMBO 361A NEMA 4 PAINTED S611 480 Vac, CPT, START/STOP PB, HOA | ECS9623CAA-C1P7S3 |
| NON-COMBO 414A NEMA 4 PAINTED S611 480 Vac, CPT, START/STOP PB, HOA | ECS9633CAA-C1P7S3 |
| NON-COMBO 52A NEMA 3R S611 208 Vac, CPT, START/STOP PB, HOA | ECS96R2EAA-C1P7S3 |
| NON-COMBO 65A NEMA 3R S611 208 Vac, CPT, START/STOP PB, HOA | ECS96S2EAA-C1P7S3 |
| NON-COMBO 77A NEMA 3R S611 208 Vac, CPT, START/STOP PB, HOA | ECS96T2EAA-C1P7S3 |
| NON-COMBO 99A NEMA 3R S611 208 Vac, CPT, START/STOP PB, HOA | ECS96V2EAA-C1P7S3 |
| NON-COMBO 125A NEMA 3R S611 208 Vac, CPT, START/STOP PB, HOA | ECS96W2EAA-C1P7S3 |
| NON-COMBO 156A NEMA 3R S611 208 Vac, CPT, START/STOP PB, HOA | ECS96X2EAA-C1P7S3 |
| NON-COMBO 180A NEMA 3R S611 208 Vac, CPT, START/STOP PB, HOA | ECS96Y2EAA-C1P7S3 |
| NON-COMBO 242A NEMA 3R S611 208 Vac, CPT, START/STOP PB, HOA | ECS96Z2EAA-C1P7S3 |
| NON-COMBO 302A NEMA 4 PAINTED S611 208 Vac, CPT, START/STOP PB, HOA | ECS9613EAA-C1P7S3 |
| NON-COMBO 361A NEMA 4 PAINTED S611 208 Vac, CPT, START/STOP PB, HOA | ECS9623EAA-C1P7S3 |
| NON-COMBO 414A NEMA 4 PAINTED S611 208 Vac, CPT, START/STOP PB, HOA | ECS9633EAA-C1P7S3 |
| NON-COMBO 52A NEMA 3R S611 240 Vac, CPT, START/STOP PB, HOA | ECS96R2BAA-C1P7S3 |
| NON-COMBO 65A NEMA 3R S611 240 Vac, CPT, START/STOP PB, HOA | ECS96S2BAA-C1P7S3 |
| NON-COMBO 77A NEMA 3R S611 240 Vac, CPT, START/STOP PB, HOA | ECS96T2BAA-C1P7S3 |
| NON-COMBO 99A NEMA 3R S611 240 Vac, CPT, START/STOP PB, HOA | ECS96V2BAA-C1P7S3 |
| NON-COMBO 125A NEMA 3R S611 240 Vac, CPT, START/STOP PB, HOA | ECS96W2BAA-C1P7S3 |
| NON-COMBO 156A NEMA 3R S611 240 Vac, CPT, START/STOP PB, HOA | ECS96X2BAA-C1P7S3 |
| NON-COMBO 180A NEMA 3R S611 240 Vac, CPT, START/STOP PB, HOA | ECS96Y2BAA-C1P7S3 |
| NON-COMBO 242A NEMA 3R S611 240 Vac, CPT, START/STOP PB, HOA | ECS96Z2BAA-C1P7S3 |
| NON-COMBO 302A NEMA 4 PAINTED S611 240 Vac, CPT, START/STOP PB, HOA | ECS9613BAA-C1P7S3 |
| NON-COMBO 361A NEMA 4 PAINTED S611 240 Vac, CPT, START/STOP PB, HOA | ECS9623BAA-C1P7S3 |
| NON-COMBO 414A NEMA 4 PAINTED S611 240 Vac, CPT, START/STOP PB, HOA | ECS9633BAA-C1P7S3 |
| NON-COMBO 52A NEMA 3R S611 575 Vac, CPT, START/STOP PB, HOA | ECS96R2DAA-C1P7S3 |
| NON-COMBO 65A NEMA 3R S611 575 Vac, CPT, START/STOP PB, HOA | ECS96S2DAA-C1P7S3 |

Effective November 2012

Table 4. Vista Registered Enclosed S611, Continued

| Description | Catalog Number |
|---|-----------------------|
| NON-COMBO 77A NEMA 3R S611 575 Vac, CPT, START/STOP PB, HOA | ECS96T2DAA-C1P7S3 |
| NON-COMBO 99A NEMA 3R S611 575 Vac, CPT, START/STOP PB, HOA | ECS96V2DAA-C1P7S3 |
| NON-COMBO 125A NEMA 3R S611 575 Vac, CPT, START/STOP PB, HOA | ECS96W2DAA-C1P7S3 |
| NON-COMBO 156A NEMA 3R S611 575 Vac, CPT, START/STOP PB, HOA | ECS96X2DAA-C1P7S3 |
| NON-COMBO 180A NEMA 3R S611 575 Vac, CPT, START/STOP PB, HOA | ECS96Y2DAA-C1P7S3 |
| NON-COMBO 242A NEMA 3R S611 575 Vac, CPT, START/STOP PB, HOA | ECS96Z2DAA-C1P7S3 |
| NON-COMBO 302A NEMA 4 PAINTED S611 575 Vac, CPT, START/STOP PB, HOA | ECS9613DAA-C1P7S3 |
| NON-COMBO 361A NEMA 4 PAINTED S611 575 Vac, CPT, START/STOP PB, HOA | ECS9623DAA-C1P7S3 |
| NON-COMBO 414A NEMA 4 PAINTED S611 575 Vac, CPT, START/STOP PB, HOA | ECS9633DAA-C1P7S3 |
| COMBO FUSIBLE (100A CLIP) 52A NEMA 3R S611 480 Vac | ECS97R2CAG |
| COMBO FUSIBLE (100A CLIP) 65A NEMA 3R S611 480 Vac | ECS97S2CAG |
| COMBO FUSIBLE (100A CLIP) 77A NEMA 3R S611 480 Vac | ECS97T2CAG |
| COMBO FUSIBLE (200A CLIP) 99A NEMA 3R S611 480 Vac | ECS97V2CAJ |
| COMBO FUSIBLE (200A CLIP) 125A NEMA 3R S611 480 Vac | ECS97W2CAJ |
| COMBO FUSIBLE (400A CLIP) 156A NEMA 4 PAINTED S611 480 Vac | ECS97X3CAL |
| COMBO FUSIBLE (400A CLIP) 180A NEMA 4 PAINTED S611 480 Vac | ECS97Y3CAL |
| COMBO FUSIBLE (400A CLIP) 242A NEMA 4 PAINTED S611 480 Vac | ECS97Z3CAL |
| COMBO FUSIBLE (600A CLIP) 302A NEMA 4 PAINTED S611 480 Vac | ECS9713CAN |
| COMBO FUSIBLE (600A CLIP) 361A NEMA 4 PAINTED S611 480 Vac | ECS9723CAN |
| COMBO FUSIBLE (600A CLIP) 414A NEMA 4 PAINTED S611 480 Vac | ECS9733CAN |
| COMBO FUSIBLE (100A CLIP) 52A NEMA 3R S611 208 Vac | ECS97R2EAG |
| COMBO FUSIBLE (100A CLIP) 65A NEMA 3R S611 208 Vac | ECS97S2EAG |
| COMBO FUSIBLE (100A CLIP) 77A NEMA 3R S611 208 Vac | ECS97T2EAG |
| COMBO FUSIBLE (200A CLIP) 99A NEMA 3R S611 208 Vac | ECS97V2EAJ |
| COMBO FUSIBLE (200A CLIP) 125A NEMA 3R S611 208 Vac | ECS97W2EAJ |
| COMBO FUSIBLE (400A CLIP) 156A NEMA 4 PAINTED S611 208 Vac | ECS97X3EAL |
| COMBO FUSIBLE (400A CLIP) 180A NEMA 4 PAINTED S611 208 Vac | ECS97Y3EAL |
| COMBO FUSIBLE (400A CLIP) 242A NEMA 4 PAINTED S611 208 Vac | ECS97Z3EAL |
| COMBO FUSIBLE (600A CLIP) 302A NEMA 4 PAINTED S611 208 Vac | ECS9713EAN |
| COMBO FUSIBLE (600A CLIP) 361A NEMA 4 PAINTED S611 208 Vac | ECS9723EAN |
| COMBO FUSIBLE (600A CLIP) 414A NEMA 4 PAINTED S611 208 Vac | ECS9733EAN |
| COMBO FUSIBLE (100A CLIP) 52A NEMA 3R S611 240 Vac | ECS97R2BAG |
| COMBO FUSIBLE (100A CLIP) 65A NEMA 3R S611 240 Vac | ECS97S2BAG |
| COMBO FUSIBLE (100A CLIP) 77A NEMA 3R S611 240 Vac | ECS97T2BAG |
| COMBO FUSIBLE (200A CLIP) 99A NEMA 3R S611 240 Vac | ECS97V2BAJ |
| COMBO FUSIBLE (200A CLIP) 125A NEMA 3R S611 240 Vac | ECS97W2BAJ |
| COMBO FUSIBLE (400A CLIP) 156A NEMA 4 PAINTED S611 240 Vac | ECS97X3BAL |
| COMBO FUSIBLE (400A CLIP) 180A NEMA 4 PAINTED S611 240 Vac | ECS97Y3BAL |
| COMBO FUSIBLE (400A CLIP) 242A NEMA 4 PAINTED S611 240 Vac | ECS97Z3BAL |
| COMBO FUSIBLE (600A CLIP) 302A NEMA 4 PAINTED S611 240 Vac | ECS9713BAN |
| COMBO FUSIBLE (600A CLIP) 361A NEMA 4 PAINTED S611 240 Vac | ECS9723BAN |
| COMBO FUSIBLE (600A CLIP) 414A NEMA 4 PAINTED S611 240 Vac | ECS9733BAN |
| COMBO FUSIBLE (100A CLIP) 52A NEMA 3R S611 575 Vac | ECS97R2DAG |
| COMBO FUSIBLE (100A CLIP) 65A NEMA 3R S611 575 Vac | ECS97S2DAG |
| COMBO FUSIBLE (100A CLIP) 77A NEMA 3R S611 575 Vac | ECS97T2DAG |
| COMBO FUSIBLE (200A CLIP) 99A NEMA 3R S611 575 Vac | ECS97V2DAJ |
| COMBO FUSIBLE (200A CLIP) 125A NEMA 3R S611 575 Vac | ECS97W2DAJ |
| COMBO FUSIBLE (400A CLIP) 156A NEMA 4 PAINTED S611 575 Vac | ECS97X3DAL |
| COMBO FUSIBLE (400A CLIP) 180A NEMA 4 PAINTED S611 575 Vac | ECS97Y3DAL |
| COMBO FUSIBLE (400A CLIP) 242A NEMA 4 PAINTED S611 575 Vac | ECS97Z3DAL |
| COMBO FUSIBLE (600A CLIP) 302A NEMA 4 PAINTED S611 575 Vac | ECS9713DAN |
| COMBO FUSIBLE (600A CLIP) 361A NEMA 4 PAINTED S611 575 Vac | ECS9723DAN |
| COMBO FUSIBLE (600A CLIP) 414A NEMA 4 PAINTED S611 575 Vac | ECS9733DAN |
| COMBO FUSIBLE (100A CLIP) 52A NEMA 3R S611 480 Vac, CPT, START/STOP PB, HOA | ECS97R2CAG-C1P7S3 |
| COMBO FUSIBLE (100A CLIP) 65A NEMA 3R S611 480 Vac, CPT, START/STOP PB, HOA | ECS97S2CAG-C1P7S3 |

Table 4. Vista Registered Enclosed S611, Continued

| Description | Catalog Number |
|---|-----------------------|
| COMBO FUSIBLE (100A CLIP) 77A NEMA 3R S611 480 Vac, CPT, START/STOP PB, HOA | ECS97T2CAG-C1P7S3 |
| COMBO FUSIBLE (200A CLIP) 99A NEMA 3R S611 480 Vac, CPT, START/STOP PB, HOA | ECS97V2CAJ-C1P7S3 |
| COMBO FUSIBLE (200A CLIP) 125A NEMA 3R S611 480 Vac, CPT, START/STOP PB, HOA | ECS97W2CAJ-C1P7S3 |
| COMBO FUSIBLE (400A CLIP) 156A NEMA 4 PAINTED S611 480 Vac, CPT, START/STOP PB, HOA | ECS97X3CAL-C1P7S3 |
| COMBO FUSIBLE (400A CLIP) 180A NEMA 4 PAINTED S611 480 Vac, CPT, START/STOP PB, HOA | ECS97Y3CAL-C1P7S3 |
| COMBO FUSIBLE (400A CLIP) 242A NEMA 4 PAINTED S611 480 Vac, CPT, START/STOP PB, HOA | ECS97Z3CAL-C1P7S3 |
| COMBO FUSIBLE (600A CLIP) 302A NEMA 4 PAINTED S611 480 Vac, CPT, START/STOP PB, HOA | ECS9713CAN-C1P7S3 |
| COMBO FUSIBLE (600A CLIP) 361A NEMA 4 PAINTED S611 480 Vac, CPT, START/STOP PB, HOA | ECS9723CAN-C1P7S3 |
| COMBO FUSIBLE (600A CLIP) 414A NEMA 4 PAINTED S611 480 Vac, CPT, START/STOP PB, HOA | ECS9733CAN-C1P7S3 |
| COMBO FUSIBLE (100A CLIP) 52A NEMA 3R S611 208 Vac, CPT, START/STOP PB, HOA | ECS97R2EAG-C1P7S3 |
| COMBO FUSIBLE (100A CLIP) 65A NEMA 3R S611 208 Vac, CPT, START/STOP PB, HOA | ECS97S2EAG-C1P7S3 |
| COMBO FUSIBLE (100A CLIP) 77A NEMA 3R S611 208 Vac, CPT, START/STOP PB, HOA | ECS97T2EAG-C1P7S3 |
| COMBO FUSIBLE (200A CLIP) 99A NEMA 3R S611 208 Vac, CPT, START/STOP PB, HOA | ECS97V2EAJ-C1P7S3 |
| COMBO FUSIBLE (200A CLIP) 125A NEMA 3R S611 208 Vac, CPT, START/STOP PB, HOA | ECS97W2EAJ-C1P7S3 |
| COMBO FUSIBLE (400A CLIP) 156A NEMA 4 PAINTED S611 208 Vac, CPT, START/STOP PB, HOA | ECS97X3EAL-C1P7S3 |
| COMBO FUSIBLE (400A CLIP) 180A NEMA 4 PAINTED S611 208 Vac, CPT, START/STOP PB, HOA | ECS97Y3EAL-C1P7S3 |
| COMBO FUSIBLE (400A CLIP) 242A NEMA 4 PAINTED S611 208 Vac, CPT, START/STOP PB, HOA | ECS97Z3EAL-C1P7S3 |
| COMBO FUSIBLE (600A CLIP) 302A NEMA 4 PAINTED S611 208 Vac, CPT, START/STOP PB, HOA | ECS9713EAN-C1P7S3 |
| COMBO FUSIBLE (600A CLIP) 361A NEMA 4 PAINTED S611 208 Vac, CPT, START/STOP PB, HOA | ECS9723EAN-C1P7S3 |
| COMBO FUSIBLE (600A CLIP) 414A NEMA 4 PAINTED S611 208 Vac, CPT, START/STOP PB, HOA | ECS9733EAN-C1P7S3 |
| COMBO FUSIBLE (100A CLIP) 52A NEMA 3R S611 240 Vac, CPT, START/STOP PB, HOA | ECS97R2BAG-C1P7S3 |
| COMBO FUSIBLE (100A CLIP) 65A NEMA 3R S611 240 Vac, CPT, START/STOP PB, HOA | ECS97S2BAG-C1P7S3 |
| COMBO FUSIBLE (100A CLIP) 77A NEMA 3R S611 240 Vac, CPT, START/STOP PB, HOA | ECS97T2BAG-C1P7S3 |
| COMBO FUSIBLE (200A CLIP) 99A NEMA 3R S611 240 Vac, CPT, START/STOP PB, HOA | ECS97V2BAJ-C1P7S3 |
| COMBO FUSIBLE (200A CLIP) 125A NEMA 3R S611 240 Vac, CPT, START/STOP PB, HOA | ECS97W2BAJ-C1P7S3 |
| COMBO FUSIBLE (400A CLIP) 156A NEMA 4 PAINTED S611 240 Vac, CPT, START/STOP PB, HOA | ECS97X3BAL-C1P7S3 |
| COMBO FUSIBLE (400A CLIP) 180A NEMA 4 PAINTED S611 240 Vac, CPT, START/STOP PB, HOA | ECS97Y3BAL-C1P7S3 |
| COMBO FUSIBLE (400A CLIP) 242A NEMA 4 PAINTED S611 240 Vac, CPT, START/STOP PB, HOA | ECS97Z3BAL-C1P7S3 |
| COMBO FUSIBLE (600A CLIP) 302A NEMA 4 PAINTED S611 240 Vac, CPT, START/STOP PB, HOA | ECS9713BAN-C1P7S3 |
| COMBO FUSIBLE (600A CLIP) 361A NEMA 4 PAINTED S611 240 Vac, CPT, START/STOP PB, HOA | ECS9723BAN-C1P7S3 |
| COMBO FUSIBLE (600A CLIP) 414A NEMA 4 PAINTED S611 240 Vac, CPT, START/STOP PB, HOA | ECS9733BAN-C1P7S3 |
| COMBO FUSIBLE (100A CLIP) 52A NEMA 3R S611 575 Vac, CPT, START/STOP PB, HOA | ECS97R2DAG-C1P7S3 |
| COMBO FUSIBLE (100A CLIP) 65A NEMA 3R S611 575 Vac, CPT, START/STOP PB, HOA | ECS97S2DAG-C1P7S3 |
| COMBO FUSIBLE (100A CLIP) 77A NEMA 3R S611 575 Vac, CPT, START/STOP PB, HOA | ECS97T2DAG-C1P7S3 |
| COMBO FUSIBLE (200A CLIP) 99A NEMA 3R S611 575 Vac, CPT, START/STOP PB, HOA | ECS97V2DAJ-C1P7S3 |
| COMBO FUSIBLE (200A CLIP) 125A NEMA 3R S611 575 Vac, CPT, START/STOP PB, HOA | ECS97W2DAJ-C1P7S3 |
| COMBO FUSIBLE (400A CLIP) 156A NEMA 4 PAINTED S611 575 Vac, CPT, START/STOP PB, HOA | ECS97X3DAL-C1P7S3 |
| COMBO FUSIBLE (400A CLIP) 180A NEMA 4 PAINTED S611 575 Vac, CPT, START/STOP PB, HOA | ECS97Y3DAL-C1P7S3 |
| COMBO FUSIBLE (400A CLIP) 242A NEMA 4 PAINTED S611 575 Vac, CPT, START/STOP PB, HOA | ECS97Z3DAL-C1P7S3 |
| COMBO FUSIBLE (600A CLIP) 302A NEMA 4 PAINTED S611 575 Vac, CPT, START/STOP PB, HOA | ECS9713DAN-C1P7S3 |
| COMBO FUSIBLE (600A CLIP) 361A NEMA 4 PAINTED S611 575 Vac, CPT, START/STOP PB, HOA | ECS9723DAN-C1P7S3 |
| COMBO FUSIBLE (600A CLIP) 414A NEMA 4 PAINTED S611 575 Vac, CPT, START/STOP PB, HOA | ECS9733DAN-C1P7S3 |
| COMBO BREAKER (70A) 52A NEMA 3R S611 480 Vac | ECS98R2CAW |
| COMBO BREAKER (100A) 65A NEMA 3R S611 480 Vac | ECS98S2CAG |
| COMBO BREAKER (150A) 65A NEMA 3R S611 480 Vac | ECS98S2CAH |
| COMBO BREAKER (100A) 77A NEMA 3R S611 480 Vac | ECS98T2CAG |
| COMBO BREAKER (150A) 77A NEMA 3R S611 480 Vac | ECS98T2CAH |
| COMBO BREAKER (150A) 99A NEMA 3R S611 480 Vac | ECS98V2CAH |
| COMBO BREAKER (250A) 99A NEMA 3R S611 480 Vac | ECS98V2CAJ |
| COMBO BREAKER (150A) 125A NEMA 3R S611 480 Vac | ECS98W2CAH |
| COMBO BREAKER (250A) 125A NEMA 3R S611 480 Vac | ECS98W2CAJ |
| COMBO BREAKER (250A) 156A NEMA 3R S611 480 Vac | ECS98X2CAJ |
| COMBO BREAKER (250A) 180A NEMA 3R S611 480 Vac | ECS98Y2CAJ |
| COMBO BREAKER (400A) 242A NEMA 3R S611 480 Vac | ECS98Z2CAK |
| COMBO BREAKER (400A) 302A NEMA 4 PAINTED S611 480 Vac | ECS9813CAK |

Effective November 2012

Table 4. Vista Registered Enclosed S611, Continued

| Description | Catalog Number |
|--|-----------------------|
| COMBO BREAKER (600A) 361A NEMA 4 PAINTED S611 480 Vac | ECS9823CAL |
| COMBO BREAKER (600A) 414A NEMA 4 PAINTED S611 480 Vac | ECS9833CAL |
| COMBO BREAKER (70A) 52A NEMA 3R S611 208 Vac | ECS98R2EAW |
| COMBO BREAKER (100A) 65A NEMA 3R S611 208 Vac | ECS98S2EAG |
| COMBO BREAKER (150A) 65A NEMA 3R S611 208 Vac | ECS98S2EAH |
| COMBO BREAKER (100A) 77A NEMA 3R S611 208 Vac | ECS98T2EAG |
| COMBO BREAKER (150A) 77A NEMA 3R S611 208 Vac | ECS98T2EAH |
| COMBO BREAKER (150A) 99A NEMA 3R S611 208 Vac | ECS98V2EAH |
| COMBO BREAKER (250A) 99A NEMA 3R S611 208 Vac | ECS98V2EAJ |
| COMBO BREAKER (150A) 125A NEMA 3R S611 208 Vac | ECS98W2EAH |
| COMBO BREAKER (250A) 125A NEMA 3R S611 208 Vac | ECS98W2EAJ |
| COMBO BREAKER (250A) 156A NEMA 3R S611 208 Vac | ECS98X2EAJ |
| COMBO BREAKER (250A) 180A NEMA 3R S611 208 Vac | ECS98Y2EAJ |
| COMBO BREAKER (400A) 242A NEMA 3R S611 208 Vac | ECS98Z2EAK |
| COMBO BREAKER (400A) 302A NEMA 4 PAINTED S611 208 Vac | ECS9813EAK |
| COMBO BREAKER (600A) 361A NEMA 4 PAINTED S611 208 Vac | ECS9823EAL |
| COMBO BREAKER (600A) 414A NEMA 4 PAINTED S611 208 Vac | ECS9833EAL |
| COMBO BREAKER (70A) 52A NEMA 3R S611 240 Vac | ECS98R2BAW |
| COMBO BREAKER (100A) 65A NEMA 3R S611 240 Vac | ECS98S2BAG |
| COMBO BREAKER (150A) 65A NEMA 3R S611 240 Vac | ECS98S2BAH |
| COMBO BREAKER (100A) 77A NEMA 3R S611 240 Vac | ECS98T2BAG |
| COMBO BREAKER (150A) 77A NEMA 3R S611 240 Vac | ECS98T2BAH |
| COMBO BREAKER (150A) 99A NEMA 3R S611 240 Vac | ECS98V2BAH |
| COMBO BREAKER (250A) 99A NEMA 3R S611 240 Vac | ECS98V2BAJ |
| COMBO BREAKER (150A) 125A NEMA 3R S611 240 Vac | ECS98W2BAH |
| COMBO BREAKER (250A) 125A NEMA 3R S611 240 Vac | ECS98W2BAJ |
| COMBO BREAKER (250A) 156A NEMA 3R S611 240 Vac | ECS98X2BAJ |
| COMBO BREAKER (250A) 180A NEMA 3R S611 240 Vac | ECS98Y2BAJ |
| COMBO BREAKER (400A) 242A NEMA 3R S611 240 Vac | ECS98Z2BAK |
| COMBO BREAKER (400A) 302A NEMA 4 PAINTED S611 240 Vac | ECS9813BAK |
| COMBO BREAKER (600A) 361A NEMA 4 PAINTED S611 240 Vac | ECS9823BAL |
| COMBO BREAKER (600A) 414A NEMA 4 PAINTED S611 240 Vac | ECS9833BAL |
| COMBO BREAKER (70A) 52A NEMA 3R S611 575 Vac | ECS98R2DAW |
| COMBO BREAKER (100A) 65A NEMA 3R S611 575 Vac | ECS98S2DAG |
| COMBO BREAKER (150A) 65A NEMA 3R S611 575 Vac | ECS98S2DAH |
| COMBO BREAKER (100A) 77A NEMA 3R S611 575 Vac | ECS98T2DAG |
| COMBO BREAKER (150A) 77A NEMA 3R S611 575 Vac | ECS98T2DAH |
| COMBO BREAKER (150A) 99A NEMA 3R S611 575 Vac | ECS98V2DAH |
| COMBO BREAKER (250A) 99A NEMA 3R S611 575 Vac | ECS98V2DAJ |
| COMBO BREAKER (150A) 125A NEMA 3R S611 575 Vac | ECS98W2DAH |
| COMBO BREAKER (250A) 125A NEMA 3R S611 575 Vac | ECS98W2DAJ |
| COMBO BREAKER (250A) 156A NEMA 3R S611 575 Vac | ECS98X2DAJ |
| COMBO BREAKER (250A) 180A NEMA 3R S611 575 Vac | ECS98Y2DAJ |
| COMBO BREAKER (400A) 242A NEMA 3R S611 575 Vac | ECS98Z2DAK |
| COMBO BREAKER (400A) 302A NEMA 4 PAINTED S611 575 Vac | ECS9813DAK |
| COMBO BREAKER (600A) 361A NEMA 4 PAINTED S611 575 Vac | ECS9823DAL |
| COMBO BREAKER (600A) 414A NEMA 4 PAINTED S611 575 Vac | ECS9833DAL |
| COMBO BREAKER (100A) 65A NEMA 3R S611 480 Vac, CPT, START/STOP PB, HOA | ECS98S2CAG-C1P7S3 |
| COMBO BREAKER (150A) 65A NEMA 3R S611 480 Vac, CPT, START/STOP PB, HOA | ECS98S2CAH-C1P7S3 |
| COMBO BREAKER (150A) 77A NEMA 3R S611 480 Vac, CPT, START/STOP PB, HOA | ECS98T2CAH-C1P7S3 |
| COMBO BREAKER (250A) 99A NEMA 3R S611 480 Vac, CPT, START/STOP PB, HOA | ECS98V2CAJ-C1P7S3 |
| COMBO BREAKER (250A) 125A NEMA 3R S611 480 Vac, CPT, START/STOP PB, HOA | ECS98W2CAJ-C1P7S3 |
| COMBO BREAKER (250A) 156A NEMA 3R S611 480 Vac, CPT, START/STOP PB, HOA | ECS98X2CAJ-C1P7S3 |
| COMBO BREAKER (400A) 302A NEMA 4 PAINTED S611 480 Vac, CPT, START/STOP PB, HOA | ECS9813CAK-C1P7S3 |
| COMBO BREAKER (600A) 361A NEMA 4 PAINTED S611 480 Vac, CPT, START/STOP PB, HOA | ECS9823CAL-C1P7S3 |

Table 4. Vista Registered Enclosed S611, Continued

| Description | Catalog Number |
|--|-----------------------|
| COMBO BREAKER (600A) 414A NEMA 4 PAINTED S611 480 Vac, CPT, START/STOP PB, HOA | ECS9833CAL-C1P7S3 |
| COMBO BREAKER (70A) 52A NEMA 3R S611 208 Vac, CPT, START/STOP PB, HOA | ECS98R2EAW-C1P7S3 |
| COMBO BREAKER (100A) 65A NEMA 3R S611 208 Vac, CPT, START/STOP PB, HOA | ECS98S2EAG-C1P7S3 |
| COMBO BREAKER (150A) 65A NEMA 3R S611 208 Vac, CPT, START/STOP PB, HOA | ECS98S2EAH-C1P7S3 |
| COMBO BREAKER (100A) 77A NEMA 3R S611 208 Vac, CPT, START/STOP PB, HOA | ECS98T2EAG-C1P7S3 |
| COMBO BREAKER (150A) 77A NEMA 3R S611 208 Vac, CPT, START/STOP PB, HOA | ECS98T2EAH-C1P7S3 |
| COMBO BREAKER (150A) 99A NEMA 3R S611 208 Vac, CPT, START/STOP PB, HOA | ECS98V2EAH-C1P7S3 |
| COMBO BREAKER (250A) 99A NEMA 3R S611 208 Vac, CPT, START/STOP PB, HOA | ECS98V2EAJ-C1P7S3 |
| COMBO BREAKER (150A) 125A NEMA 3R S611 208 Vac, CPT, START/STOP PB, HOA | ECS98W2EAH-C1P7S3 |
| COMBO BREAKER (250A) 125A NEMA 3R S611 208 Vac, CPT, START/STOP PB, HOA | ECS98W2EAJ-C1P7S3 |
| COMBO BREAKER (250A) 156A NEMA 3R S611 208 Vac, CPT, START/STOP PB, HOA | ECS98X2EAJ-C1P7S3 |
| COMBO BREAKER (250A) 180A NEMA 3R S611 208 Vac, CPT, START/STOP PB, HOA | ECS98Y2EAJ-C1P7S3 |
| COMBO BREAKER (400A) 242A NEMA 3R S611 208 Vac, CPT, START/STOP PB, HOA | ECS98Z2EAK-C1P7S3 |
| COMBO BREAKER (400A) 302A NEMA 4 PAINTED S611 208 Vac, CPT, START/STOP PB, HOA | ECS9813EAK-C1P7S3 |
| COMBO BREAKER (600A) 361A NEMA 4 PAINTED S611 208 Vac, CPT, START/STOP PB, HOA | ECS9823EAL-C1P7S3 |
| COMBO BREAKER (600A) 414A NEMA 4 PAINTED S611 208 Vac, CPT, START/STOP PB, HOA | ECS9833EAL-C1P7S3 |
| COMBO BREAKER (70A) 52A NEMA 3R S611 240 Vac, CPT, START/STOP PB, HOA | ECS98R2BAW-C1P7S3 |
| COMBO BREAKER (100A) 65A NEMA 3R S611 240 Vac, CPT, START/STOP PB, HOA | ECS98S2BAG-C1P7S3 |
| COMBO BREAKER (150A) 65A NEMA 3R S611 240 Vac, CPT, START/STOP PB, HOA | ECS98S2BAH-C1P7S3 |
| COMBO BREAKER (100A) 77A NEMA 3R S611 240 Vac, CPT, START/STOP PB, HOA | ECS98T2BAG-C1P7S3 |
| COMBO BREAKER (150A) 77A NEMA 3R S611 240 Vac, CPT, START/STOP PB, HOA | ECS98T2BAH-C1P7S3 |
| COMBO BREAKER (150A) 99A NEMA 3R S611 240 Vac, CPT, START/STOP PB, HOA | ECS98V2BAH-C1P7S3 |
| COMBO BREAKER (250A) 99A NEMA 3R S611 240 Vac, CPT, START/STOP PB, HOA | ECS98V2BAJ-C1P7S3 |
| COMBO BREAKER (150A) 125A NEMA 3R S611 240 Vac, CPT, START/STOP PB, HOA | ECS98W2BAH-C1P7S3 |
| COMBO BREAKER (250A) 125A NEMA 3R S611 240 Vac, CPT, START/STOP PB, HOA | ECS98W2BAJ-C1P7S3 |
| COMBO BREAKER (250A) 156A NEMA 3R S611 240 Vac, CPT, START/STOP PB, HOA | ECS98X2BAJ-C1P7S3 |
| COMBO BREAKER (250A) 180A NEMA 3R S611 240 Vac, CPT, START/STOP PB, HOA | ECS98Y2BAJ-C1P7S3 |
| COMBO BREAKER (400A) 242A NEMA 3R S611 240 Vac, CPT, START/STOP PB, HOA | ECS98Z2BAK-C1P7S3 |
| COMBO BREAKER (400A) 302A NEMA 4 PAINTED S611 240 Vac, CPT, START/STOP PB, HOA | ECS9813BAK-C1P7S3 |
| COMBO BREAKER (600A) 361A NEMA 4 PAINTED S611 240 Vac, CPT, START/STOP PB, HOA | ECS9823BAL-C1P7S3 |
| COMBO BREAKER (600A) 414A NEMA 4 PAINTED S611 240 Vac, CPT, START/STOP PB, HOA | ECS9833BAL-C1P7S3 |
| COMBO BREAKER (70A) 52A NEMA 3R S611 575 Vac, CPT, START/STOP PB, HOA | ECS98R2DAW-C1P7S3 |
| COMBO BREAKER (100A) 65A NEMA 3R S611 575 Vac, CPT, START/STOP PB, HOA | ECS98S2DAG-C1P7S3 |
| COMBO BREAKER (150A) 65A NEMA 3R S611 575 Vac, CPT, START/STOP PB, HOA | ECS98S2DAH-C1P7S3 |
| COMBO BREAKER (100A) 77A NEMA 3R S611 575 Vac, CPT, START/STOP PB, HOA | ECS98T2DAG-C1P7S3 |
| COMBO BREAKER (150A) 77A NEMA 3R S611 575 Vac, CPT, START/STOP PB, HOA | ECS98T2DAH-C1P7S3 |
| COMBO BREAKER (150A) 99A NEMA 3R S611 575 Vac, CPT, START/STOP PB, HOA | ECS98V2DAH-C1P7S3 |
| COMBO BREAKER (250A) 99A NEMA 3R S611 575 Vac, CPT, START/STOP PB, HOA | ECS98V2DAJ-C1P7S3 |
| COMBO BREAKER (150A) 125A NEMA 3R S611 575 Vac, CPT, START/STOP PB, HOA | ECS98W2DAH-C1P7S3 |
| COMBO BREAKER (250A) 125A NEMA 3R S611 575 Vac, CPT, START/STOP PB, HOA | ECS98W2DAJ-C1P7S3 |
| COMBO BREAKER (250A) 156A NEMA 3R S611 575 Vac, CPT, START/STOP PB, HOA | ECS98X2DAJ-C1P7S3 |
| COMBO BREAKER (250A) 180A NEMA 3R S611 575 Vac, CPT, START/STOP PB, HOA | ECS98Y2DAJ-C1P7S3 |
| COMBO BREAKER (400A) 242A NEMA 3R S611 575 Vac, CPT, START/STOP PB, HOA | ECS98Z2DAK-C1P7S3 |
| COMBO BREAKER (400A) 302A NEMA 4 PAINTED S611 575 Vac, CPT, START/STOP PB, HOA | ECS9813DAK-C1P7S3 |
| COMBO BREAKER (600A) 361A NEMA 4 PAINTED S611 575 Vac, CPT, START/STOP PB, HOA | ECS9823DAL-C1P7S3 |
| COMBO BREAKER (600A) 414A NEMA 4 PAINTED S611 575 Vac, CPT, START/STOP PB, HOA | ECS9833DAL-C1P7S3 |

Eaton Corporation
Electrical Sector
1111 Superior Avenue
Cleveland, OH 44114 USA
Eaton.com

© 2012 Eaton Corporation
All Rights Reserved
Printed in USA
Publication No. MZ123001EN / Z12944
November 2012



Eaton is a registered trademark
of Eaton Corporation.

All other trademarks are property
of their respective owners.